

GuardTag Manual

This personal alarm features a dual siren design with the two sirens sounding at different frequencies. The dual sirens oscillate to maximise attention. The compact design allows the personal alarm to be discreetly carried on a key ring, purse etc. The idea is to be prepared, so take the personal alarm wherever you go. It is recommended the personal alarm be carried when walking alone, entering buildings, hallways, elevators, parking lots etc.



Directions: Remove the plastic battery protection slip from the back of the alarm. To activate the alarm, pull the pin from the plastic housing. A 120dB siren will sound. To de-activate, slide the pin back into the alarm until it snaps in place. It is recommended that the personal alarm be tested periodically to ensure battery performance. Replace the batteries if the sound is not working.

To change the batteries: The shelf battery life is approximately 12 months (standby mode). It is recommended that the alarm power is regularly tested by activating the alarm. When the alarm siren goes weak, please replace the batteries. Using a screwdriver, remove the battery cover on the back. Remove the old batteries and dispose of them properly. Replace the four new 2XCR2032 batteries as shown. Do not mix old and new batteries or mix batteries.

Storage: Remove batteries before storing the alarm for an extended period of time to prevent batteries from corroding or damaging the alarm.

Remember: Do not solely rely on any self-defense product for protection. Avoid dangerous, isolated, and poorly lit areas, and travel with others where possible. Take reasonable precautions to avoid situations where self-defense will become necessary.

Batteries: Requires 2XCR2032 alkaline batteries (included).

Caution: Batteries may leak harmful liquids or ignitable materials or explode causing injury and product damage.

Warning: Risk of personal injury. Prolonged exposure to alarm sirens may cause permanent hearing loss.

