

 beatbuds pro



User Manual

Appearance



- A. Charging Contactor
- B. Touching Area
- C. Microphone
- D. Digital LED Display
- E. Charging port

Product Specification:

- Bluetooth Version: V5.1
- Stand-by time: 120 days
- Talk time: 4-5 hours
- Charging time: 60 mins
- Battery capacity: 35 mAh
- Charging voltage: DC 5V
- Transmission distance: 10m -15m
- Frequency response: 20-20000 Hz
- Charging case : 300 mAh
- Music playtime: 5-6 hours

1

How to start using the BeatBuds Pro:

- When using the product for the first time, remove the clear plastic film on the bottom of the BeatBuds!
- Use the USB charger that comes with the product to charge the BeatBuds before trying to pair them. When they are charging in their case the case light will flash red.
- When they are fully charged you can pair them and continue to use!
- If you would like to adjust the size according to your ears, please make use of the extra ear pieces that came with the product.
- If the earphones lose their pairing function: Turn on the BeatBuds --> Turn off the Bluetooth on the device --> Double tap on the right earphone to get them to pair manually.

1. To turn the BeatBuds on

Open the case, and the earphones should automatically turn on. Or to do this manually, press the right earphone for 3 seconds.

2. To turn the BeatBuds off

The BeatBuds will turn off when putting them into the charging case and closing the lid. Or manually press the right earphone for 5 seconds to turn them off. (If the BeatBuds are not connected, they will automatically turn off after 3 minutes)

3. Bluetooth pairing

Once the BeatBuds are turned on, they will be in auto-pair mode. Open Bluetooth on the device you are wanting to pair them with and select "TWS" to connect. The indication light on the BeatBuds will disappear once connected.

2

(The BeatBuds will automatically auto pair with the device that you paired with before. If need connect to other devices, please refer to Bluetooth pairing steps.)

4. Charging indication

- When the BeatBuds case is charging, the red light will blink. When it is fully charged the red light will stop flashing.
- When you remove the BeatBuds from charge the light will go blue which means it is fully charged.
- When the BeatBuds are charged, the blue light will flash when removed from the case

5. Phone call mode

When a call comes in, to answer tap the left or right earphone. To reject a call you can press either BeatBud for about 2 seconds. During the call, you can tap either BeatBud to hang up.

6. Other tips:

- *Single-tap left or right earphone : Play/Pause, Answer/Hang up
- *Double-tap: Left earphone-->skip back, right earphone-->skip forward
- *Triple-tap: Left earphone -->volume down, right earphone -->volume up
- *Long tap left or right earphone for 2 seconds: To activate or close voice Assistance function.

Safety information

Before using and operating the BeatBuds, please read and follow the below precautions to ensure the best performance and to avoid dangerous or illegal situations.

Electronic Devices

- Do not use this device in a place where wireless devices are prohibited, otherwise it will interfere with other electronic devices or cause other dangers

3

Medical equipment interference

- In medical and health care places where the use of wireless devices is prohibited, please follow the rules and turn off the device.
- The radio waves generated by the device may affect the normal operation of implanted medical devices or personal medical devices, such as pacemakers, cochlear implants, hearing aids, etc. If you use these medical devices, please consult the manufacturer for restrictions on the use of this device.
- When using this device, please keep at least 15 cm away from implanted medical devices (such as pacemakers, cochlear implants, etc.).

Hearing Loss

- Sound at a high volume may permanently damage your hearing.
- When you use earphones to listen to music or calls, it is recommended to use the minimum volume required for music or calls to avoid damaging your hearing.
- Exposure to high-level volume while driving, your attention may be distracted and cause accidents.

Operating environment

- Do not use the device in dusty, compact areas or near magnetic fields to avoid failure of the internal circuit of the device.
- When installing the device, please keep away from strong magnetic fields or electrical appliances with strong magnetic fields, such as ovens and refrigerators.
- Do not use the device in thunderstorm weather. Thunderstorms may cause equipment to fail or become an electrical shock hazard.
- Please use the device within a temperature range of -10 ° C ~ + 55 ° C, and store the device and its accessories within a temperature range of -40 ° C ~ + 70 ° C. When the temperature is too high or too low, it may cause device function failure. When the temperature is below 5 ° C, the performance of the battery is limited.

4

- Do not place the device in direct sunlight, such as the dashboard of a car or a window sill.
- Do not place the device near heating sources or exposed fire sources, such as electric heaters, water heaters, ovens, stoves, candles, or other places that may generate high temperatures.
- Do not place sharp metal objects such as pins near the device's earpiece or speaker, otherwise the metal objects may adhere and cause injury to you.

Child health

- This device and its accessories may contain some small parts. Keep the device and its accessories in a place out of reach from children. Children may damage the device and its accessories, or swallow small parts, causing suffocation or other hazards.
- This device is not a toy, children should use this device under adult supervision.

Battery safety

- Do not disassemble or modify the battery, or immerse it in water or other liquids, to avoid battery leakage, excessive, fire or explosion.
- Do not drop, crush or puncture the battery. It can cause internal short circuits and overheating.
- This device is equipped with a non-removable built-in battery. Do not replace the battery yourself to avoid damage to the battery or device.
- Please dispose batteries in accordance with local regulations. Do not dispose batteries as household waste. Improper disposal of the battery may cause the battery to explode.

Charger safety

- When charging the device, the power socket should be installed near the device and should be easily accessible.
- When charging is completed or not charging, disconnect the charger from the device and unplug the charger from the power outlet.

5

Environmental protection

- Do not dispose this device and its accessories as ordinary household garbage.
- Please abide by the local laws and regulations on the handling of this device and its accessories, and support recycling operations.

Precautions:

- The BeatBuds should be stored in a dry environment and avoid contact with oil, water vapor, steam, moisture and dust to prevent negatively affecting the performance of the product.
- Avoid using harsh organic solvents or items containing these ingredients to clean the BeatBuds.
- The earphones should be used correctly according to the manual, and pay attention to the warnings.
- Make sure the connection is clear and a maximum distance of 10 meters between the device and the BeatBuds.
- If the earphones failed to connect or have a poor connection, please do not dismantle them or the accessories yourself. Otherwise, there is no warranty.
- When charging the earphones, please use the charging cord supplied by our company.
- To ensure normal use of the BeatBuds, please make sure they are fully charged.

6

深圳恩乐实业有限公司产品说明书

物料名称	TW60 蓝讯杰里通用耳机说明书S-1.2	物料号码	307-BC-0086
工 艺	彩色印刷, 风琴折页	日 期	2020-08-18
材 质	材质: 105g铜版纸 (双铜)	设 计	王金松
规 格	480mm*80mm	确 认	周 雄