


OSCILLATING AIR COOLER FAN
Instruction Manual
Model: F2

Dear Customer, thanks for choosing our products. It is important that you read these instructions before using your new cooler fan and we strongly recommend that you keep in a safe place for future reference.

PRODUCT INTRODUCTION



- | | | | |
|---------------|-------------------|---------------------|-----------------|
| 1.ON/OFF | 5.Lights | 9.Fan | 13.Water tank |
| 2.Speed | 6.Timer | 10. Louvers | 14.Air inlet |
| 3.Oscillation | 7.Indicator light | 11.Rotating base | 15.Type-C |
| 4.Humidifier | 8.Handle | 12.Water tank cover | 16.Water drawer |

Product specifications

Model:	F2
Name:	OSCILLATING AIR COOLER FAN
Size:	15*10.8*24.3CM
Input:	DC5V=2A
Work Temperature:	0°C~50°C
Wind-Speed:	Four
Water Tank:	Approx. 600ml

User guides

- 1.Take out the cooler fan from the package.
- 2.Remove the water tank cover. And then pour in tap water or mineral water. (Noted:1.Do not pour in distilled water or purified water, or will damage the humidifier. 2. Do not fill over the maximum line, or will pour out to the desk.)
- 3.Connect the Type-C side to the device and USB side to the adapter, and then the power indicator light will illuminate. (Noted: The input adapter must be $\geq 5V/2A$. Because the adapter will affect the device working and wind output etc.)
- 4.Click the button to turn ON/OFF the cooler fan. (Default mode: first wind speed)
- 5.Repeat click button to switch the wind speed. Indicator light to I means first wind speed,II means second wind speed, III means third wind speed, all means fourth wind speed.
- 6.Click button to turn ON/OFF oscillation function.

7.Click button to turn ON/OFF humidifying function. Indicator light to I means first gear humidifying capacity, II means second gear humidifying capacity.

8.Click button to turn ON/OFF the colorful light. The color of light will automatically changing.

9.Click button to turn ON/OFF the timer function. It has 2H/4H/6H for choosing.

10.The angle of wind could be adjustable from louvers.

11.Working with humidifier function, when water level runs low than min line, the cooler fan will turn off the humidifier function automatically.

Noted: It is normal to have water droplets on the shell when working. It will automatically flow into the water drawer. You need to pour out the excess water before use (recommended to clean once a day). When cleaning the water tank, please be sure to clean the water in the water drawer first, avoid to damage the device.

Maintenance and cleaning:

- 1.Turn off the product and remove the power plug before cleaning, maintaining or moving.
- 2.Only clean after the fan has stopped completely.
- 3.Do not soak the power cord or device in water for cleaning or washing under the tap, and the internal parts of the fan shall not be wet.
- 4.Do not use detergent, wire brush, gasoline, alcohol, vinegar or other volatile corrosive liquid to cleaning the product, or will damage the product.
- 5.Clean the fan surface with a damp cloth.
- 6.After cleaning, the product must be completely dry before reconnect to power supply.
- 7.If not used for a long time, please put back the product in the package and put in a dry,cool and safe place.

Attentions:

- Before using, please ensure that the input voltage $\geq 5V/2A$.
- In order to avoid electric shock, no parts should be in contact with water.
- Do not cover the air inlet and outlet.
- Be sure to tighten the water tank cover when using.
- Add water shall not exceed than the highest water level.
- To avoid water overflow, do not shake the device when the water tank is full.
- Do not twist the device manually, or will damage the shaking motor and rotating gear.
- Do not add oil to the water tank to avoid corrosion of the product.
- Do not blow the wind directly to the elderly, infants or people with limited mobility for a long time.
- Please do not put the fan in the bathroom, damp and high temperature places, or will damage the product.
- Keep the fan away from curtains, door curtains and other soft objects to avoid sucked into the fan.
- When the power cord or the product damaged or unsafe. Please stop to use and contact the maintenance center of the product for inspection and repair. Do not inspection and repair by yourself.
- When the cooler fan is not used for a long time, please remove the power plug, avoid to reduce the lifespan and causing accident or danger.
- Do not disassemble the product by yourself to avoid damage and electric shock!
- Do not put fingers and other body parts or sundries into the fan's inlet/outlet ,avoid to damage the product.

120MM

90MM

说明书尺寸：90X120mm
材质：105g铜板纸