骨传导蓝牙耳机 使用指南及保修说明	示意图及配件         ①       ①         ①       ①         ①       ①         ①       ①         ①       ①         ①       ①         ①       ②         ①       ②         ①       壹         ①       壹         ①       壹         ①       壹         ①       壹         ①       壹         ①       壹         ①       壹         ①       壹         ①       壹         ①       壹         ①       壹         ①       壹         ①       壹         ①       □         ①       壹         ①       □         ①       □         ①       □         ①       □         ①       □         ①       □         ①       □         ①       □         ②       □         ②       □         ②       □         ②       □         ③       □         ③	使用说明 开机 长按开机键约3秒,当指示灯红蓝交替闪烁,表示耳机已 经开机. <b>蓝牙连接</b> 首次使用,耳机正常开机后,会进入蓝牙配对状态,此时手机蓝 牙设置里可搜索到"K08",点击连接成功后指示灯灭灯,播放音 乐蓝灯5秒闪烁一次. <b>更换配对设备及回连</b> 断开当前配对设备蓝牙,耳机指示灯红蓝交替闪烁,其他设备即 可搜索到"K08"点击连接,"K08"骨传导耳机支持自动回连配对设备 正常开机后即会自动回连,最后一次连接的设备,请确保前端 (如手机蓝牙)正常开启。 关机 长按开关键约3秒即会关机.指示灯熄灭. <b>充电</b> 正常连接,手机会显示耳机电量,如电量显示红色,即表 示需要充电,插入充电线充电即可. 备注:5V充电设备如手机充电器都可进行充电.	操作说明 <b>开关键/多功能复合键</b> 长按开关键3秒 耳机开关机 长按1秒开关键出提示音松开:唤醒Siri <b>播放状态</b> 单击开关键键 暂停播放 长按*-*键2秒 下一曲 长按*-*键2秒 下一曲 短按**-*键 音量加 短按***键2秒 音量減 <b>来电状态</b> 短按开关键 接听 短按开关键 挂断 长按开关键1秒 拒接 长按开关键2秒 手机与耳机音源切换 <b>指示灯说明</b> 红蓝交替: 配对状态 红灯常亮: 正在充电 蓝灯常亮: 充满电量	产品参数 *型号: GC17 *版本:5.3 *重量:25g *电池:160mAh *充电:约2小时 *播放:约5H&70%音量 *通话:-38±3dB *防水:IP55 *距离:蓝牙10米 *输入:5V/130mA *协议:a2dp 1.3\avctp 1.4\avdtp 1.3\ avrcp 1.5\hfp 1.5 spp 1.0\rfcomm 1.2\pnp 1.3\hid 1.0\sdp core4.2 l2cap core 4.2	故障及排除 无法开机 确定耳机是否充满电量,按键是否误操作,同时充电激活. 无法蓝牙连接 耳机指示灯是否处于红蓝交替闪阶段,如耳机处于蓝灯呼吸状, 表示耳机与其他设备已经连接,需要断开当前连接设备. 无法回连 确定前端(如手机蓝牙)是否正常开启. 耳机音量较小 手机是否加大音量,需要手机增加或减小音量.佩戴方式 是否正确	格       近         上       C.Passed         产品保修卡          该卡为产品保修凭证,请妥善保管         产品名称:       产品型号:         购买日期:       客户名称:         联系方式:          产品维修记录          日期       不良现象       解决方案         日期       不良现象          日期       小
----------------------	--	--	---	--	---	---



duct parameters	Troubleshooting Unable to boot Determine whether the headset is fully charged, whether the button is misoperated, and then charge and activate.			
del: GC17 rsion: 5.3				
ight: 25g	Unable to connect to Bluetooth			
tery: 160 mah	Whether the headphone indicator is in the alternately flashing stage			
arging: About 2 hours	of red and blue, such as the headphone is in the breathing state of			
y :5H&70% volume	blue light,			
ce: -38±3dB	Indicates that the headset has been connected to other devices			
terproof: IP55	and needs to disconnect the current connected device.			
tance: Bluetooth 10 meters	Can't back to even			
ut: 5 y / 500 ma	Make sure the front end (e.g., Bluetooth) is open properly.			
itocol: a2dp 1.3\avctp 1.4\avdtp 1.3\ avrcp 1.5\hfp 1.5	Headphone volume is low			
5 1.0\rfcomm 1.2\pnp 1.3\hid 1.0\sdp core4.2	Whether the phone increases the volume, the phone needs to			
ap core 4.2	increase or decrease the volume. Wearing a way Whether it is right			