


ULTRASONIC DOG TRAINER



Preface


Hello, thank you for your choice and trust!:)

I am a user manual. Let me tell you how to use ultrasonic dog trainer correctly.

Ultrasonic dog trainer device Uses the principle of ultrasonic wave to stimulate the dog, then the dog will stop its current behavior.


For example, you can expel a dog coming towards you. When the device is turned on, it emits a frequency of 10kHz-30kHz, which is difficult for human hearing, but it is a sensitive frequency for dogs. However, the sound will not bring negative effects on the hearing or health of dogs. It is an effective and safe product.

Operating Guide:



1

Product parameters



Product Name: Dog trainer

Charging: Type-C

Application range: 1-10m

Function: Dog training, Stop barking,

Ultrasonic frequency: 10kHz-30kHz


Tease the dog

Battery: 3.7V/1200mAh lithium battery

Material: ABS plastic

2

Function description



• There are three modes of gear adjustment:

Gear 1: ultrasonic frequency band 25kHz

Gear 2: ultrasonic frequency band 10kHz-25kHz

Gear 3: ultrasonic frequency band 10kHz-30kHz

• Ultrasonic switch:

Please press and hold the switch button, the work indicator light will be green, and the equipment will send the ultrasonic frequency training dog corresponding to the gear until the key is released or it stops automatically after 10 seconds.

• Laser light switch:

Press and hold the switch button, and the device will turn on the laser light to amuse the dog until it is released.

• LED light switch:

Short press the white light to flash, which can cooperate with the ultrasonic wave to stop the dog barking. Short press the white light again to keep the light on. Short press the third time to turn off the light.

3

• After long-term adaptation, animals' hearing will be immune to certain sounds, so you can use different gears periodically to extend the effective availability of the product.

• The working distance of dog trainer is 1-10 meters, which is suitable for outdoor use.

Battery

1. When the device shows low power, please charge it as soon as possible.

2. When charging, the device lights up the red indicator, and the red indicator will go out after it is fully charged.

3. After fully charged, please remove the power supply as soon as possible to avoid prolonged charging.

4. When the battery is damaged, do not repair or disassemble it.

5. Charging time is about 4-6 hours.

6. Do not use adapters larger than 5V2A to charge the product.

7. This product uses 1100 mAh battery.

8. Do not immerse the product in water or extreme environments (below 0°C or above 45°C). Extreme environments may shorten the service life of the product.

4

Notice

1. Using this product means that you accept all terms and conditions.
2. This product is not suitable for dogs with strong defensive ability, and has no effect on old or hearing impaired dogs.
3. Different dogs may react differently to sound waves. For best results, you can use this product with other dog trainer tools.
4. This product is a professional dog trainer equipment and cannot be used for other purposes. Please do not use this product in violation of local laws.
5. The company shall not be liable for any direct or indirect damage caused by the use or misuse of this product, and all risks of using this product shall be borne by the user.

Made in China



5