

## LED HEADLAMP USER MANUAL

Thank you for using this product. Please read the instructions carefully and follow them strictly for using safely. Please keep the manual properly for future reading.



### 【Product specifications】

Lamp beads: COB\*3+XPE\*1

Material: ABS + Silicone Rubber

Power supply: Built-in rechargeable battery

Battery: 2200mAh\*2

Charging method: USB charging

Charging time: 2-3 hours

Lighting time: 4-8 hours

Irradiation distance: up to about 100 yards.

Wide beam: 230°

Motion sensor: Yes

Waterproof level: IPX5

Charge voltage/current: 5v/0.5A

### Light Mode:

- Press the power switch to enter the COB-White 100% lighting mode
- Press again to enter COB-White 50% lighting mode

- Press the third time to enter COB-Yellow 100% lighting mode
- Press the fourth time to enter COB-Yellow 50% lighting mode
- Press the fifth time to enter COB-Red 100% lighting mode
- Press the sixth time to enter COB-Red flash mode
- Press the seventh time to enter Side-XPE 100% lighting mode
- Press the eighth time to enter Side-XPE 50% lighting mode
- Press the ninth time to turn off the power
- Long press to enter COB-White&Yellow 100% lighting mode
- Press again to enter COB-White&Yellow flash mode
- Press the third time to turn off the power

### 【Note】

In order to prevent the problem of not being able to charge in the future, please do not run out of electricity before recharging.

### 【Package】

2\*Headlamp

2\*USB Charging Cable

1\* User Manual

**If you encounter any problems with the headlamp, you can contact us at any time and we will give you a 100% satisfactory answer.**

We have listed some problems and solutions you may encounter, and hope to help you.

| Abnormal situation                                       | Reasons              | Solution   |
|--|----------------------|--|
| The headlamp is not bright or the brightness is very dim | Low battery          | Please charge the headlamp before use                  |
| The headlamp will not stay on                            | Flash mode may be on | Please press the switch again to switch to other modes |